(LUZ Instruction Manual)



AC 220V




Please read the instruction manual before installation. Please turn off the power supply before installation, operated by professional personnel.

Once the ceiling is not strong enough, suggest to use self-made wooden frame for connecting. Avoid using wet cloth to clean the fitting. The light source of this product is not replaceable, when damaged or reached the service life should be replaced, and do a good job of recycling. Please do not assemble the product without authorization, any damage caused by disassembling without authorization will no longer be covered by the warranty.

			-		
Model		Input	Dimension(mm)	Cutout(mm)	Remark
81053318 81032968	81032900 81053328	AC 220V~240V	Ø65*H76	Ø55	
81032288 81032540	81012080 81012090	AC 220V~240V	Ø85*H102	Ø75	
81054428 81054818 81053068	81054448 81053038 81054878	AC 220V~240V	Ø110*H125	Ø100	
81054828 81054648 81054908	81054858 81054888 81053268	AC 220V~240V	Ø135*H139	Ø125	
81012880 81012890 81054988	81054978 81012910 81012920	AC 220V~240V	Ø160*H157	Ø150	

Cutout



demand to meet the lighting requirements.

Please ensure that the wires are conneced correctly before turning on the power Adjustable downlight series can adjust the irradiation angle according to the supply. Do not look emitting lights directly to avoid burning your eyes.